



GutterScrew™

REPLACES OLD SPIKES

Replaces Old Popping Gutter Spikes!

- Oversized thread diameter tightly fills the existing spike hole for better holding strength and a watertight fit
- #3 square drive virtually eliminates cam-out during hard-to-reach installations
- Durable UV resistant white and brown head-paint matches most gutter systems
- Thick galvanized base coating guaranteed not to rust or react with aluminum
- Free driver bit included
- American made



For more information or free samples, call FastenMaster at 800-518-3569.

GutterScrew™

REPLACES OLD SPIKES

INSTALLATION PROCEDURE

For existing gutters installed using spikes, first remove the existing spike and ferrule. With a standard drill install the FastenMaster GutterScrew and ferrule using the #3 square drive bit provided. For new gutter installations, pre-drill a ¼" hole with spacing as recommended by the gutter manufacturer. Then install the new gutter screw and ferrule as instructed above. Note that the 7" FastenMaster GutterScrew is recommended for use with 5" standard residential gutter systems.

FMGUTSHEET (0211)

Part Number	Screw Length	Color	Qty. per Pack
FMGUT007-10BR	7"	Brown	10
FMGUT007-10W	7"	White	10
FMGUT007-25BR	7"	Brown	25
FMGUT007-25W	7"	White	25

PRODUCT FEATURES

#3 SQUARE DRIVE
REDUCES BIT
CAM-OUT

WHITE OR BROWN
COLOR MATCHED HEAD

GUARANTEED
CORROSION RESISTANT
ZINC BASECOAT
ELIMINATES RED RUST

.310 DIAMETER THREAD
GRIPS EXISTING .250
DIAMETER HOLE

